

# Installation Guide

## Part Number PJ4001

97-06 Jeep TJ Wrangler  
Rear Tube Fenders



Tube Fenders are shipped unpainted by PureJeep.  
Fenders can be painted to match your vehicle or can be painted black.

### Hardware List

Tube Fender -	Right
Tube Fender -	Left
1/4-20 x 1" Bolt:	16
1/4" Metal Lock Nut:	16
1/4" Flat Washer:	32

1. Remove factory rear plastic flares.
2. Using supplied 1/4" hardware, install Purejeep tube fenders to the vehicle using factory holes.
3. Using a 1/4" drill bit, drill a hole in the bedside of the vehicle to secure the bottom front and rear corners of the new tube fenders.
4. Tighten all hardware

