



## **PJ5101: TJ/LJ STEERING BOX SKID INSTRUCTIONS**



- 1 - Skidplate**
- 2 - 1/2" x 1" Bolts**
- 1 - 1/2" Lock Nut**
- 3- 7/16" Flat Washer**
- 1 - 5/16" x 1 Self Tap**
- 1 - 5/16" Flat Washer**

The PUREJEEP skidplate will reuse the stock bolts on the steering box. The included 1/2" bolts will be installed on the bottom of the skid and along the lower part of the front bumper.

The included self tapping bolt will install on the inside portion of the frame rail.